

SERVICE BULLETIN

CAB SERVICE & PARTS CORPORATION

SUBSIDIARY OF
CHECKER MOTORS
CORPORATION

NEW YORK * BROOKLINE
CHICAGO * DETROIT

#22

January 1, 1959

Subject: STEERING - MODEL A-9
Description: FRONT SHOCK ABSORBER

REMOVE

1. Remove locknut-washer and rubber bushing from upper stud on top of dome on the frame.
2. Remove bolts which hold shock absorber mounting plate on lower control arm.
3. Remove shock absorber.

REPLACE

1. Install washers, bushings, bushing seat and mounting plate on lower end of shock absorber.
2. Install stud lock nut on lower end and tighten.*
3. Install 1 washer and bushing on upper end and position shock absorber in coil spring.
4. Install lower mounting plate to frame bolts.
5. Install bushing seat, bushing and washer on upper stud.
6. Install upper stud nut and tighten.*

*Torque Pull: Stud lock nut 25-35 lbs.

By: NEW YORK SERVICE DEPARTMENT