

February 14, 1962  
#3 Model A-11 & A-12

ENGINEERING MEMORANDUM #3

TO: J. Stout, PD. Visser, RH. Fuller, BS. Wilson, S. Magyes, D. Eacorrigan,  
K. Luke, F. Leamy (3), R. McCulford, R. Radke (3), W. Asselin, R. Smith,  
A. Goedhart, E. Nelson, C. Cornwell, R. Big Herrington (8), R. Bach,  
D. Markin, F. Baldwin, L. J. Copeland, W. J. Coleman, P. Tan Bedard, B. Karbothe,  
L. Hilsky (4), W. Temple (4)

FROM: S. Hori

The first eighty-nine (89) A-12W6 & A-12W8 Aerobuses will be built using the Model A-10WS6 & A-10WS8 Doors, Door Hardware, Center Pillars, Lock Strikers, Door Trim Panels, and Garnish Moldings to use up the existing parts.

LIST OF MODEL A-10WS6 & A-10WS8 PARTS REQUIRED FOR THE FIRST (89) A-12W6 & A-12W8 AEROBUSES ONLY.

PART NO.	PART NAME	BUY OR MAKE	NO. REQ'D./JOB	
			A-12W6	A-12W8
630007	Panel-Center Pillar Front LH	Make	2	3
630008	Panel-Center Pillar Front RH	Make	2	3
630003	Reinf.-Pillar Striker Depress.	Make	6	8
625440	Retainer-Dr. Lk. Striker T.P.	Make	6	8
625441	Plate-Dr. Lk. Striker Tap.	Buy	12	16
636325	Panel-Rear Pillar Frt. LH	Make	1	1
636326	Panel-Rear Pillar Frt. RH	Make	1	1
632545	Panel-Frt. Dr. Inner LH	Make	1	1
632546	Panel-Frt. Dr. Inner RH	Make	1	1
631335	Reg. Assem-Frt. Dr. Wind. LH	Buy	1	1
631336	Reg. Assem-Frt. Dr. Wind. RH	Buy	1	1
631337	Lock Assem-Door LH	Buy	3	4
631338	Lock Assem-Door RH	Buy	3	4
637077	Remote Cont. & Lk. Assem-Frt. Dr. LH	Buy	1	1
637078	Remote Cont. & Lk. Assem-Frt. Dr. RH	Buy	1	1
638081	Sleeve-R. Cont. Lk. Brkt.	Buy	12	16
638079	Brkt.-Rem. Cont. Lk.	Make	6	8
634237	Panel-Frt. Door Outer LH	Make	1	1
634238	Panel-Frt. Door Outer RH	Make	1	1
625915	Handle-Remote Control	Buy	6	8
624651	Handle Assem-Regulator	Buy	6	8
635538	Escutcheon Assem-Reg. & Rem. Cont.	Buy	12	16
631375	Handle Assem-Frt. Dr. Lock LH	Buy	1	1
631919	Handle Assem-Frt. Dr. Lock RH	Buy	1	1
630753	Mldg. - Frt. Dr. Garn. LH	Make	1	1
630754	Mldg. - Frt. Dr. Garn. RH	Make	1	1
630207	W/Strip - Frt. Dr. Wind.	Buy	2	2
636695	Panel-Ctr. Dr. Inner LH	Buy	1	2
636696	Panel-Ctr. Dr. Inner RH	Buy	1	2
634971	Brkt. Door Arm Rest	Make	12	16
631391	Reg. Assem-RR. Dr. Wind. LH	Buy	2	3
631392	Reg. Assem-RR. Dr. Wind. RH	Buy	2	3
630752	Mldg. - RR. Dr. Wind. Garn.	Make	4	6
630244	W/Strip - RR. Dr. Wind.	Buy	4	6

February 14, 1962

PART NO.	PART NAME	BUY OR MAKE	NO. REQ'D./JOB	
			A-12W6	A-12W8
632543	Panel-RR. Dr. Inner LH	Make	1	1
632544	Panel-RR. Dr. Inner RH	Make	1	1
637077	Rem. Cont.& Lk. Assem-Door LH	Buy	2	3
637078	Rem. Cont.& Lk. Assem-Door RH	Buy	2	3
633723	Supt. & Pad Assem-Arm Rest(Blk.) LH	Buy	3	4
633724	Supt. & Pad Assem-Arm Rest(Blk.) RH	Buy	3	4
634979	Frame-Dr. Armrest (Gray) LH	Buy	3	4
634980	Frame-Dr. Armrest (Gray) RH	Buy	3	4
624523	Striker Assem-Comp.D'Tail & Dr.Lk.LH	Buy	3	4
624522	Striker Assem-Comp.D'Tail & Dr.LK.RH	Buy	3	4
635527	Pan Assem-Frt.Door Trim LH(Dk. Gray)	Buy	1	1
635528	Pan Assem-Frt.Door Trim RH(Dk. Gray)	Buy	1	1
635529	Pan Assem-RR.Door Trim LH (Dk. Gray)	Buy	2	3
635530	Pan Assem-RR.Door Trim RH (Dk. Gray)	Buy	2	3

Special New Lock Package required for these cars to include New  
Glove Compartment Lock for New Instrument Panel.

639670	Lock Package-Keyed(Indiv.)Man,T/G (Spec.)	Buy	1	1
This package to include				
633245	Plug Assem-Ign.,Door & T/G(Indiv.)	Furn.	4	4
639217	Lock Assem.-Glove Compt. (Indiv.)	Furn.	1	1
634328	Key-Ign.,Door,T/G & Glove Compt. (Indiv.)	Furn.	2	2

Note: This Lock Package can be used on Manual Tailgate Jobs Only.

ASSUMED TO HAVE BEEN USED PRIOR TO CHASSIS NO. 1481.  
DEFINITE NO. NOT REPORTED,