



HOSES and CLAMPS—HEATING SYSTEM

Illus. Key	Part No.	Description	No. Req'd.
	142269	BUSHING - Cylinder Head Water Outlet Reducing	1
	82113	VALVE ASSEMBLY - Heater Shut Off 90°	2
	92816	HOSE - Cylinder Head Water Outlet To Under Seat Heater	1
		HOSE - Dash Mounted Heater To Under Seat Heater	1
	92818	CLAMP - Cylinder Head Water Outlet And Under Seat Heater Connection Hose	4
	92817	HOSE - Under Seat Heater To Water Pump	1
	92818	CLAMP - Under Seat Heater To Water Pump Hose Connection	2
	92819	LOOM - Under Seat Heater Hose Insulator	1
	92517	BRACKET - Under Seat Heater Hose Mounting	1
	138540	WASHER - Under Seat Heater Hose Bracket To Steering Gear Stud Lock	1
	115729	NUT - Under Seat Heater Hose Bracket To Steering Gear Stud	1
	82123	CLIP - Under Seat Heater Hose Double	3
	124052	SCREW - Under Seat Heater Hose Clip To Bracket	1
	118773	WASHER - Under Seat Heater Hose Clip To Bracket Plain	1
	115109	WASHER - Under Seat Heater Hose Clip To Bracket Lock	1
	118613	NUT - Under Seat Heater Hose Clip To Bracket	1
	80727	CLIP - Under Seat Heater Hose Band	2
	92920	HOSE - Cylinder Head Outlet To Dash Mounted Heater	1
	92924	CLIP - Dash Mounted Heater Hose To Distributor Adjusting Bolt	1
	92818	CLAMP - Dash Mounted Heater Inlet And Outlet Hose	2
	92921	GROMMET - Dash Mounted Heater Core Tubes At Dash Panel	2