



AXLE ASSEMBLY-REAR

ILLUSTRATION No. 6



AXLE ASSEMBLY—REAR

Illus. Key	Part No.	Description	No. Req'd.
6-1	92346	AXLE ASSEMBLY - Rear (Less Hubs - Drums And Brakes) 3.54-1 Ratio (Use With Automatic Transmission)	1
6-2	92347	AXLE ASSEMBLY - Rear (Less Hubs - Drums And Brakes) 4.09-1 Ratio	1
6-3	92348	AXLE ASSEMBLY - Rear (Less Hubs - Drums And Brakes) 4.55-1 Ratio	1
6-4	64512	NUT - Rear Axle Pinion Yoke Lock	1
6-5	64513	WASHER - Rear Axle Pinion Yoke Nut	1
6-6	63563	YOKE AND SHIELD ASSEMBLY - Rear Axle Pinion	1
6-7	N. S. S.	YOKE - Rear Axle Pinion	1
6-8	63523	SHIELD - Rear Axle Pinion Yoke Dust	1
6-9	63535	SEAL - Rear Axle Pinion Oil	1
6-10	64514	GASKET - Rear Axle Pinion Oil Seal	1
6-11	64515	SLINGER - Rear Axle Pinion Oil	1
6-12	63538	CONE - Rear Axle Pinion Outer Bearing	1
6-13	63539	CUP - Rear Axle Pinion Outer Bearing	1
6-14	63540	SHIM - Rear Axle Pinion Outer Bearing Adjusting .003	As Req'd
6-15	63541	SHIM - Rear Axle Pinion Outer Bearing Adjusting .005	As Req'd
6-16	63542	SHIM - Rear Axle Pinion Outer Bearing Adjusting .010	As Req'd
6-17	63543	SHIM - Rear Axle Pinion Outer Bearing Adjusting .030	As Req'd
6-18	63545	SHIM - Rear Axle Pinion Inner Bearing Adjusting .003	As Req'd
6-19	63546	SHIM - Rear Axle Pinion Inner Bearing Adjusting .005	As Req'd



AXLE ASSEMBLY—REAR (cont'd)

Illus. Key	Part No.	Description	No. Req'd.
AXLE ASSEMBLIES - Rear (Cont'd)			
6-20	63547	SHIM - Rear Axle Pinion Inner Bearing Adjusting .010	As Req'd
6-21	63549	CUP - Rear Axle Pinion Inner Bearing	1
6-22	64516	CONE - Rear Axle Pinion Inner Bearing	1
6-23	64501	HOUSING AND BEARING CAPS ASSEMBLY - Rear Axle	1
6-24	N.S.S.	HOUSING AND TUBES ASSEMBLY - Rear Axle	1
6-25	N.S.S.	CAP - Rear Axle Differential Bearing	2
6-26	64502	SCREW - Rear Axle Differential Bearing Cap	4
6-27	807	PLUG - Rear Axle Housing Drain	1
6-28	64507	DIFFERENTIAL ASSEMBLY - Rear Axle - 3.54-1 Ratio (Use With Automatic Transmission)	1
6-29	63585	DIFFERENTIAL ASSEMBLY - Rear Axle - 4.09-1 Ratio	1
6-30	64518	DIFFERENTIAL ASSEMBLY - Rear Axle - 4.55-1 Ratio	1
6-31	64508	PINION AND GEAR - Rear Axle Differential (Matched Set) 3.54-1 Ratio (Use With Automatic Transmission)	1
6-32	63584	PINION AND GEAR - Rear Axle Differential (Matched Set) 4.09-1 Ratio	1
6-33	64519	PINION AND GEAR - Rear Axle Differential (Matched Set) 4.55-1 Ratio	1
6-34	N.S.S.	PINION - Rear Axle Differential	1
6-35	N.S.S.	GEAR - Rear Axle Differential Ring	1
6-36	64510	CASE ASSEMBLY - Rear Axle Differential 3.54-1 Ratio (Use With Automatic Transmission)	1
6-37	63590	CASE ASSEMBLY - Rear Axle Differential 4.09-1 Ratio And 4.55-1 Ratio	1



AXLE ASSEMBLY—REAR (cont'd)

Illus. Key	Part No.	Description	No. Req'd.
AXLE ASSEMBLIES - Rear (Cont'd)			
DIFFERENTIAL ASSEMBLIES - Rear Axle (Cont'd)			
CASE ASSEMBLIES - Rear Axle Differential (Cont'd)			
6-38	64511	CASE - Rear Axle Differential 3.54-1 Ratio (Use With Automatic Transmission)	1
6-39	63591	CASE - Rear Axle Differential 4.09-1 Ratio And 4.55-1 Ratio	1
6-40	63573	KIT - Rear Axle Differential Thrust Washers, Shaft, Pinion And Side Gear Repair	1
6-41	63576	WASHER - Rear Axle Differential Side Gear Thrust	1
6-42	63510	SHAFT - Rear Axle Differential Pinion Mate	1
6-43	63509	PIN - Rear Axle Differential Lock	1
6-44	63513	BLOCK - Rear Axle Differential Axle Shaft Thrust	1
6-45	63512	WASHER - Rear Axle Differential Pinion Thrust	1
6-46	63574	KIT - Rear Axle Differential Pinion And Side Gear Repair	1
6-47	63512	WASHER - Rear Axle Differential Pinion Thrust	1
6-48	63576	WASHER - Rear Axle Differential Side Gear Thrust	1
6-49	63517	CUP - Rear Axle Differential Bearing	2
6-50	63516	CONE - Rear Axle Differential Bearing	2
6-51	63519	SHIM - Rear Axle Differential Bearing Adjusting .003	As Req'd
6-52	63520	SHIM - Rear Axle Differential Bearing Adjusting .005	As Req'd
6-53	63521	SHIM - Rear Axle Differential Bearing Adjusting .010	As Req'd
6-54	63522	SHIM - Rear Axle Differential Bearing Adjusting .030	As Req'd



AXLE ASSEMBLY—REAR (cont'd)

Illus. Key	Part No.	Description	No. Req'd.
AXLE ASSEMBLIES - Rear (Cont'd)			
6-55	64509	SCREW - Rear Axle Differential Ring Gear To Case	10
6-56	114942	NUT - Rear Axle Wheel Bearing Retainer To Tube Flange Bolt	12
6-57	115093	WASHER - Rear Axle Wheel Bearing Retainer To Tube Flange Bolt Lock	12
6-58	63554	BOLT - Rear Axle Wheel Bearing Retainer To Tube Flange	12
6-59	63555	RETAINER - Rear Axle Wheel Bearing	2
6-60	63561	CUP - Rear Axle Wheel Bearing	2
6-61	63560	CONE - Rear Axle Wheel Bearing	2
6-62	64503	SEAL - Rear Axle Shaft Oil	2
6-63	63556	SHIM - Rear Axle Wheel Bearing Adjusting .003	As Req'd
6-64	63557	SHIM - Rear Axle Wheel Bearing Adjusting .005	As Req'd
6-65	63558	SHIM - Rear Axle Wheel Bearing Adjusting .010	As Req'd
6-66	63559	SHIM - Rear Axle Wheel Bearing Adjusting .030	As Req'd
6-67	63553	SHAFT - Rear Axle	2
6-68	63550	NUT - Rear Axle Shaft	2
6-69	63587	GASKET - Rear Axle Differential Housing Cover	1
6-70	63588	COVER ASSEMBLY - Rear Axle Differential Housing	1
6-71	N. S. S.	COVER - Rear Axle Differential Housing	1
6-72	103869	PLUG - Rear Axle Differential Housing Filler	1
6-73	64506	BOLT AND LOCKWASHER ASSEMBLY - Rear Axle Differential Cover To Housing	10
6-74	119512	FITTING - Rear Axle Wheel Bearing Lubrication	2